Codes of Collect data for automatic mode

```
# IPython Libraries for display and widgets
import ipywidgets
import traitlets
import ipywidgets.widgets as widgets
from IPython. display import display
# Camera and Motor Interface for JetBot
from jetbot import Robot, Camera, bgr8 to jpeg
# Basic Python packages for image annotation
from uuid import uuid1
import os
import json
import glob
import datetime
import numpy as np
import cv2
import time
from jupyter clickable image widget import ClickableImageWidget
DATASET DIR = 'dataset xy'
# we have this "try/except" statement because these next functions can throw an
error if the directories exist already
try:
   os. makedirs (DATASET DIR)
except FileExistsError:
   print('Directories not created because they already exist')
camera = Camera()
# create image preview
camera widget = ClickableImageWidget(width=camera.width, height=camera.height)
snapshot_widget = ipywidgets.Image(width=camera.width, height=camera.height)
traitlets.dlink((camera, 'value'), (camera_widget, 'value'),
transform=bgr8_to_jpeg)
# create widgets
count widget = ipywidgets. IntText(description='count')
# manually update counts at initialization
```

```
count_widget.value = len(glob.glob(os.path.join(DATASET_DIR, '*.jpg')))
def save_snapshot(_, content, msg):
    if content['event'] == 'click':
        data = content['eventData']
        x = data['offsetX']
        y = data['offsetY']
        # save to disk
        #dataset. save_entry(category_widget.value, camera.value, x, y)
        uuid = 'xy_{03d_{03d_{8}}} (x, y, uuid1())
        image_path = os.path.join(DATASET_DIR, uuid + '.jpg')
        with open(image_path, 'wb') as f:
            f.write(camera widget.value)
        # display saved snapshot
        snapshot = camera.value.copy()
        snapshot = cv2. circle(snapshot, (x, y), 8, (0, 255, 0), 3)
        snapshot_widget.value = bgr8_to_jpeg(snapshot)
        count_widget.value = len(glob.glob(os.path.join(DATASET_DIR, '*.jpg')))
camera_widget.on_msg(save_snapshot)
data_collection_widget = ipywidgets.VBox([
    ipywidgets. HBox([camera widget, snapshot widget]),
    count_widget
])
display(data_collection_widget)
camera.stop()
    def timestr():
        return str(datetime.datetime.now().strftime('%Y-%m-%d_%H-%M-%S'))
    !zip -r -q road_following_{DATASET_DIR}_{timestr()}.zip {DATASET_DIR}
```